


Assembly Instruction Door adjustments 039178

The product contains one or more of following materials: Wood, metal, plastic.




EFG Pulse - Door adjustments


When the Cabinet is leveled the Doors might need to be adjusted so they are straight and have even gaps all around.




Installation of doors.




Dismantling of doors.



Inactivation of Blumotion (soft closing).



Activation of Blumotion



Height adjustment.



Left / Right adjustment.



In / Out adjustment.

2