


IZI NIVEAU AND IZI PRO


EFG IZI DESK RESET




1. Pull out electrical cord for at least 10 seconds.



2. Hold both buttons at the same time for 10 seconds.



3. Move to the lowest position and hold for 10 seconds.



4. Done. Test by moving up.